

Regardless of the type & shape hood corners you have seen, these are the correct shape & material verified by originals & archive blueprint. The way you receive them is the way they are sewn & not how they are installed. Refold them along the two impressions to a triangle shape with seam & hole in back. Transfer front hole from hood, insert rivit & upset in rear. Chromed calf is a soft leather and may not cut 100% clean edge. The fuzz is easily removed with scissors. Also, the restorer may desire to color the cut edge with black dye or paint.