

~~Mr. Geagan~~

18200A

# INSTALLATION INSTRUCTIONS FOR 28-29 OPEN CAR WIND WING BRACKETS

Measure the area on the body or door post on which the bracket will be mounted. Tape the bracket into place.

Cut a template from  $\frac{1}{4}$ " material (plywood or fiber board) the same size as the glass that will be installed. Assemble the gripper and install the template on the windshield post clamps.

Check all clearances to make sure wind wings will open properly.

Mark the areas where holes will be drilled making sure there will be room for the nuts on the back side. Center punch for drilling.

Drill holes.

Install glass.

