

BRAKE SHOE CENTERING TOOL

Mount this tool on the front spindle or rear axle secured by the axle nut. Set the adjustable finger on the tool just off the brake lining. Rotate the tool around the circumference of the brake shoes. The finger must be the same distance off the shoes all the way around. If not, the shoes will not completely contact the drum. If say the top half of the shoes to finger gap is larger than the bottom, then use a crescent wrench to make the adjustment. Slide the wrench over the roller track ear and bend both ears down. Reverse the bend if the gap is in the bottom half.

BRATTON'S **ANTIQUÉ AUTO PARTS**



800-255-1929 Phone
www.brattons.com

800-774-1930 Fax
1606 Back Acre Circle
Mount Airy, MD 21771

Your source for Quality Model A Ford Parts since 1976