

**P/N 2870 (2870)**  
**THE 3/8" DIAMETER PINS**

We have seen up to .010 wear in the original rectangular hole of the P/N 2850 (A-2050) operating wedge. Some repro wedge holes are about .012 larger than the original specification. It is important to have a good fit in the length of the pin so the wedge does not twist. We have included a pair of stock length and a second pair of pins that are extra long for the customer to grind for a .001 slip fit into the wedge, this will eliminate endplay inside the rectangular hole of the wedge.

**BRATTON'S**  
**ANTIQUÉ AUTO PARTS**



**800-255-1929 Phone**  
**[www.brattons.com](http://www.brattons.com)**

800-774-1930 Fax  
1606 Back Acre Circle  
Mount Airy, MD 21771

*Your source for Quality Model A Ford Parts since 1976*