

Replace the lower plug with the gauge plug and gasket. Push the plastic tube over the hose barb and insert the wire. Bend the tube into a U shape along the side of the bowl. Set the fuel level $5/8$ " below the gasket flange by bending the float hinge or adding valve gaskets