

## **INSTRUCTIONS FOR OIL GAUGE**

**Female pipe fitting goes on back of oil gauge, 90° fitting goes into block below distributor an inch above the oil pan. Remove the slotted screw plug and replace it with the 90° fitting. Run line through the terminal block on the firewall and keep oil line away from the exhaust manifold, as it will melt. Do not use teflon tape on the oil gauge or fitting going into the block. You can use liquid teflon on block but not on gauge.**